



Use  
3/8" / 0.95cm  
diameter  
dowel


## Boarding Bridge Extension Tail




## Side Stairs




## Side Stairs



# Dual Jetway 1:200 - Page 2 of 2



## Jetway Support



Use  
3/8" / 0.95cm  
diameter  
dowel



Use 1/4" / 0.635cm  
diameter dowel



Use 1/8" / 0.317cm  
diameter dowel

